

SECTION 09 27 13 — PART 3: EXECUTION (GFRG)

Condensed installation notes based on GFRG product sheet and shop drawings.

- **Substrate Preparation**

Ensure substrate is clean, dry, level, and prepared for fastening.

- **Attachment**

Attach using screws into embedments; shim for joint alignment.